

G.I. M1917A1 TRIPOD PROJECT

Build your own M1917A1 tripod for Browning. We built a bunch of them for our project. They are all sold now and we don't have time to do more.

Parts to repair:

1. Cut rear legs - fix it with standard size tubing.
2. Side plates could be slightly bent but are not cut.
3. Tripod head has pie shaped piece cut out (included).
4. Fork is cut vertically w/torch and tip is cut off the pintle. Pintle tip gone.
5. pintle block is cut.
6. windage screw is cut.

As-Is, No Returns

Special Of The Month \$225.00 ea, 3 for \$599.00

MNT086



GUN PINTLE NOT INCLUDED
Project lovers build your own tripod for one third the cost of a complete tripod assy

Note: Overall leg lengths for your rebuild
Front: 23" overall Rear: 27" overall